



NEW ITEM CODE	ITEM CODE	HSN CODE	ITEM	STD./ MST. PKG.
SWITCHES				
10DB111XXSWBBFT	DB 111	8536	1 Gang 1W Switch 16A	1/10
10DB112XXSWBBFT	DB 112	8536	1 Gang 2W Switch 16A	1/10
10DB113XXSWBBFT	DB 113	8536	2 Gang 1W Switch 16A	1/10
10DB114XXSWBBFT	DB 114	8536	2 Gang 2W Switch 16A	1/10
10DB115XXSWBBFT	DB 115	8536	3 Gang 1W Switch 16A	1/10
10DB116XXSWBBFT	DB 116	8536	3 Gang 2W Switch 16A	1/10
10DB117XXSWBBFT	DB 117	8536	4 Gang 1W Switch 16A	1/10
10DB118XXSWBBFT	DB 118	8536	4 Gang 2W Switch 16A	1/10
SWITCHES				
10DB121XXSWBBFT	DB 121	8536	20A Switch	
10DB122XXSWBBFT	DB 122	8536	45A Switch	
SOCKETS				
10DB119XXSSBBFT	DB 119	8536	Universal Socket with Switch 13A	1/10
10DB120XXSWBBFT	DB 120	8536	Universal Socket 16A	1/10
10DB123XXSWBBFT	DB 123	8536	One 13A Square Socket with Switch	1/10
10DB124XXSWBBFT	DB 124	8536	One 13A Square Socket with Double Pole Switch	1/10
10DB125XXSWBBFT	DB 125	8536	One 13A Square Socket with Switch + One USB 1.5A	1/10
10DB126XXSWBBFT	DB 126	8536	One 13A Square Socket with Double Pole Switch + One USB 1.5A	1/10
10DB170XXSWBBFT	00 000	8536	Double Universal Socket 13A with Switch	1/5
10DB127XXSWBBFT	DB 127	8536	Double 13A Square Socket with Switch	1/5
10DB128XXSWBBFT	DB 128	8536	Double 13A Square Socket with Double Pole Switch	1/5
10DB129XXSWBBFT	DB 129	8536	Double 13A Square Socket with Switch + 2 USB 2.1A	1/5
10DB130XXSWBBFT	DB 130	8536	Double 13A Square Socket with 2 Double Pole Switch + 2 USB 2.1A	1/5
10DB131XXSWBBFT	DB 131	8536	One 15A 3 Round Pin Socket with Switch	1/10
10DB132XXSWBBFT	DB 132	8536	One 13A Double Pole Switch with Fuse	1/10

NEW ITEM CODE	ITEM CODE	HSN CODE	ITEM	STD./ MST. PKG.
16A TV / COMPUTER / DIMMER / SOCKETS				
10DB133XXSWBBFT	DB 133	8536	45A Switch + 13A Square Socket	1/5
10DB134XXSKBBFT	DB 134	8536	TV Socket	1/10
10DB135XXJKBBFT	DB 135	8536	Computer Socket	1/10
10DB136XXJKBBFT	DB 136	8536	Telephone Socket	1/10
10DB137XXSKBBFT	DB 137	8536	TV + Telephone Socket	1/10
10DB138XXSKBBFT	DB 138	8536	TV + Computer Socket	1/10
10DB139XXJKBBFT	DB 139	8536	Double Computer Socket	1/10
10DB140XXJKBBFT	DB 140	8536	Telephone + Computer Socket	1/10
10DB141XXSWBBFT	DB 141	8536	Emergency Switch	1/10
10DB142XXDMBBFT	DB 142	8536	Dimmer	1/5
10DB143XXRGBBFT	DB 143	8536	Fan Control	1/5
10DB144XXLFBBFT	DB 144	8536	Foot Lamp	1/10
10DB145XXLFBBFT	DB 145	8536	Foot Lamp with Sensor	1/10
SWITCHES				
10DB149XXFOBBFT	DB 149	8536	Flex Outlet	1/10
10DB150XXSWBBFT	DB 150	8536	Bellpush Switch	1/10
10DB152XXSKBBFT	DB 152	8536	Shaver Socket	1/5
10DB154XXDMBBFT	DB 154	8536	LED Dimmer 100W	1/5
10DB155XXBPBBFT	DB 155	8536	Single Blank Plate	1/10
10DB156XXBPBBFT	DB 156	8536	Double Blank Plate	1/10
10DB157XXCVXOFT	DB 157	8536	Waterproof Outdoor Switch & 13A Socket Vertical Cover (Weather and Dust Proof to Rating IP66)	1/0
10DB158XXCVXOFT	DB 158	8536	Waterproof Outdoor Switch & 13A Socket Horizontal Cover (Weather and Dust Proof to Rating IP66)	1/0

